

# Installation Instructions

for use by heating contractor



## Burner Gaskets

for use with: Vitodens 100-W, WB1A and WB1B  
Vitodens 200-W, WB2, WB2B, B2HA and B2HB  
Vitodens 222-F B2TA and B2TB  
Vitocrossal 300, CU3A

### Safety and Installation Requirements

Please ensure that these instructions are read and understood before starting any service work. Failure to comply with these instructions may cause product/property damage, severe personal injury and/or loss of life.

#### Working on the equipment

The installation, adjustment, service and maintenance of this product must be performed by a licensed professional heating contractor who is qualified and experienced in the installation, service, and maintenance of hot water boilers. There are no user serviceable parts on the boiler, burner or control.

Ensure that main power to the equipment being serviced is off.

Ensure that the main fuel supply valve to the boiler is closed.

Take precautions to avoid accidental activation of power or fuel during service work.

Do not perform service work on any component part without ensuring safe operation of the heating system. When replacing parts, use original Viessmann or Viessmann approved replacement parts.



Refer to the Installation and Start-up/Service Instructions applicable to this boiler.

### Installation of Gaskets



#### WARNING

Improperly installed burner gaskets can lead to flue gas leakage.  
Ensure correct orientation during installation.  
Please see following tables.






### Vitodens 100-W

Boiler	Gasket Part No.	
WB1A	7836177	
WB1B	7836177	

#### Legend

- Ⓐ Burner mounting flange profile
- Ⓑ Burner gasket

**Vitodens 200-W / 222-F / Vitocrossal 300**

Boiler	Gasket Part No.	
WB2 6-24C, 6-24, 8-32	7818117	
WB2 11-44, 15-60	7817185	
WB2 11-44, 15-60 CU3A 26-57	7817692	
WB2B 19-35 WB2B 45-105 B2HA / B2TA 19-35 B2HA 45-100 B2HB / B2TB 19-35	7836177 7836178 7836177 7836178 7836177	
B2HA 112 - 150	7835164	

**Legend**

- (A) Burner mounting flange profile
- (B) Burner gasket
- (C) Fan housing profile



Refer to the Installation and Service Instructions applicable to this boiler.

Printed on environmentally friendly (recycled and recyclable) paper.



Technical information subject to change without notice.