


McDonnell & Miller


Installation & Maintenance Instructions MM-305(F)

Valve, Cartridge and Strainer UL Replacement Kit

Assembly Kit SA-47-101-102 for Series 47, 247 and 847 Mechanical Water Feeders

Assembly Kit SA51-101-102 for Series 51 and 851 Make-Up Water Feeders





SP


Engineered for life


INSTALLATION

TOOLS NEEDED:

One (1) long nose pliers, one (1) flathead screwdriver, and one (1) Allen wrench.

STEP 1 - Preparation






STEP 2 - Remove the Original Valve, Cartridge and Strainer

a. Using long nose pliers, remove cotter pin (D) and pivot pin (E) and discard. Remove four (4) screws (F).
NOTE: Newer models have Allen screws.


STEP 3 - Install the New Valve, Cartridge and Strainer

- 1a. For one-piece and two-piece float arms: with the valve linkage ears (H) straddling the float arm (G), install the valve. Reinstall the four (4) screws (F). Tighten to approximately 10 lb•ft (13.6 N•m) of torque.
- Align the float arm holes (G) with the valve linkage and insert the pivot pin. Insert new cotter pin (D) into new pivot pin (E) and bend the cotter pin.





McDonnell & Miller



INSTALLATION COMPLETE

MAINTENANCE

SCHEDULE:

- Disassemble and inspect the strainer annually. Thoroughly clean the strainer screen or replace.
- Remove and inspect cartridge annually. Thoroughly clean by rinsing with clear water or replace.

©2007 ITT Corporation Printed in U.S.A. 7-07 246739