# resideo Wi-Fi 9000 Thermostat

# SUBMITTAL SHEET

Job Name	Model(s)			
Engineer	TH9320WF5003	Qty.	Notes	
Mechanical Contractor	Approval	•		
Contractor's P.O. No.	Service			
Representative	Tag No.			
Notes				

# APPLICATION

Wi-Fi 9000 allows remote access through a Smartphone, Tablet or Computer. It controls up to 3H/2C heat pump systems and up to 2H/2C conventional systems. Thermostat is selectable for Residential or Light Commercial applications.

- The thermostat is equipped with a high-definition touchscreen display.
- Provides Remote Access through Smartphone, Tablet or Computer when connected to Wi-Fi and registered to mytotalconnectcomfort.com
- · Customize the screen color to match any décor.

# SPECIFICATIONS

## **Terminal Designations:**

TH9320WF Thermostat: R, RC, C, W-O/B, W2-AUX/E, Y, Y2, G, L, K

# **Electrical Ratings:**

Terminal	Voltage (50/60 Hz)	Max. Current Rating
W - 0/B	18 to 30 VAC	1.00A
Y (cooling)	18 to 30 VAC	1.00A
G (fan)	18 to 30 VAC	0.50A
W2 - Aux/E	18 to 30 VAC	1.00A
Y2 (Cooling)	18 to 30 VAC	1.00A

# Wi-Fi Communication Requirements:

802.11 b/g/n routers Android or IOS Smartphone, tablet or device

# Dimensions (in.):

3 1/2 in. High, 4 1/2 in. Wide, 7/8 in. Deep

Dimensions (mm.): 88 mm. High, 115 mm. Wide, 22 mm. Deep

Display Size: 8.06 sq in

Tri-Lingual Display: (selectable for English, French or Spanish)

Supply Voltage: 18 to 30 Vac

Switch Positions: (System) HEAT-OFF-COOL-AUTO-EM.HEAT

Switch Positions: (Fan) AUTO-ON-CIRC-FOLLOW SCHEDULE

**Operating Temperature Range:** 32 °F to 120 °F (0 °C to 48.9 °C)

**Temperature Sensor Accuracy:** ± 1.5 °F at 70 °F (0.75 °C at 21.0 °C)

# **Temperature Setting Range:**

(Adjustable high limit for heat. Adjustable low limit for cool.) Heating: 40 to 90 °F (4.5 to 32 °C) Cooling: 50 to 99 °F (10 to 37 °C)

# **Operating Humidity Range:**

(% RH)5 to 90% RH, non-condensing

Power Method: Hardwired (C-wire)

Color: Premier White®

Display: Color Touchscreen

Programmability: 7 Day Program or Non-Programmable

## Scheduling:

On-line scheduling or locally at thermostat. Residential or non-residential program schedules. Holiday scheduling for non-residential applications.





# **Humidity Sensor Accuracy:**

± 5% RH from 30% to 50% RH at 75 °F (24 °C)

## **Cool Indication:**

Displays "Cool On" when the thermostat turns the cooling on.

# Heat Indication:

Displays "Heat On" when the thermostat turns the heating on.

### **Auxiliary Heat Indication:**

Displays "Aux Heat On" when the thermostat turns the auxiliary heat on.

# **Interstage Differential:**

The thermostat keeps the indoor temperature within 1 degree of the setpoint. The thermostat turns on stage 2 when the capacity on stage 1 reaches 90%.

#### **Clock Accuracy:**

If not connected to Wi-Fi: 1 minute per month at 77 °F (25 °C). ± 2 minutes per month over the operating ambient temperature range.

If connected to Wi-Fi and registered to Total Connect Comfort: the current time is synced via the Internet.

# Mounting Means:

Thermostat mounts directly on the wall in the living space using mounting screws and anchors provided. Fits a horizontal 2 x 4 in. junction box. Use a cover plate and its mounting bracket to mount the thermostat onto a vertical 2 x 4 in. junction box.

Alerts and reminders: on display and through app.



Resideo Technologies, Inc. 1985 Douglas Drive North, Golden Valley, MN 55422 1-800-468-1502 33-00341-02 M.S. Rev. 06-21 | Printed in United States

www.resideo.com

© 2020 Resideo Technologies, Inc. All rights reserved. This product is manufactured by Resideo Technologies, Inc. and its affiliates.